



UNIVERSIDAD NACIONAL DEL ENTRE RÍOS
FACULTAD DE INGENIERÍA
CENTRO DE MEDIOS
BIBLIOTECA

Contents

Preface xvii

Acknowledgments xxiii

1 An Introduction to Computer Diagnostics 1

Architecture of the PC 2 A Preliminary Diagnostics Checklist 5
The Importance of PC Diagnostics 6

A BRIEF INTRODUCTION TO ERROR DETECTION 6

How Much Do We Need To Know? 7 Removing the Psychological
Stumbling Block 7 Introduction to Computer Jargon 8

PRELIMINARY PROBLEM-SOLVING SUGGESTIONS 9

System Not Yet in Service 9 System Not Fully Operational 10
System Malfunctioning 10 Boot and Reboot Procedure 11

SETTING UP THE WORK AREA 11

Food, Drink, and Smoking Taboos 12 Ventilation Requirements 13
Power Requirements 13 Static Electricity 14 Smoke and
Water Damage 14 Service Contracts 15

2 Preventive and Corrective Maintenance 17

Preventive Maintenance Procedures 17 Keyboard 18 Display Screen 20 Diskette Drive 20 Diskettes 21 Hard Disk Drives 23 System Unit and Adapters 23 Cable and Adapter Connectors 25 Impact Printers 25 Laser Printers 26 Corrective Maintenance Procedures 28 General Problem-Isolation Suggestions 29

3 System Diagnostics 31

System Modification Considerations 31 Diagnostic Categories 32 The POST Procedure 32 POST Procedures 33 Additional MCA System Tests During POST 33 Error Messages During POST 34 POST Video Error Code 35 A POST Error Simulation 35 POST Summary 36 POST Failure 38

ROUTINE DIAGNOSTICS 39

Diagnostics Nomenclature 40 Supplementary Diagnostics Diskettes 42 Diagnostics Diskette Preparation 42 ISA System Copy and Merge Procedures 43 Updated ISA Diagnostics Diskettes 44 COMMAND.COM and Format Programs on ISA Diagnostics and MCA Starter/Reference Diskettes 44 Main Menu (all PS/2 systems) 47 Start Routine Diagnostics (All Systems) 50 The Select an Option or Services Menu 55 Run Diagnostic/Testing Routines 59 The System Checkout Menu (PC, XT, AT only) 61 Test Notes (all systems) 64 Conclude Routine Diagnostics 70 MCA Advanced Diagnostics 70 Examples of a Test Failure 71 Diagnostics on IBM-Compatible Systems 73 Troubleshooting Diagnostics 73 Software Error Message 73 Configuration Error Message 75 Error Code 75 System Lockup 76 Frequently Encountered Error Codes 77 Erroneous Error Codes 77

4 Configuration and Batch Files 81

THE CONFIGURATION FILE 82

Creating a CONFIG.SYS File 83

THE DEVICE DRIVER 85

Resident Device Drivers 85 Additional IBM Device Drivers 85

TREE-STRUCTURED DIRECTORIES 89

Root and Subdirectories 89 Accessing a Subdirectory 90

THE BATCH FILE 91

The AUTOEXEC.BAT File	92	Multipurpose Batch Files	92
Creating and Saving a Batch File	93	Batch File Enhancements	94
A Batch File/Electronic Disk Application	96		
CONFIGURATION AND BATCH FILE DIAGNOSTICS	98		
The DOS Environment and Environment Space Error	98	Other	
CONFIG.SYS and AUTOEXEC.BAT Errors	99		
CONFIGURATION AND BATCH FILE SUMMARY	101		
5 Electric Power and the Power Supply Unit	103		
ELECTRICAL TERMINOLOGY	103		
VOLTAGE REQUIREMENTS FOR IBM PCS	104		
Power versus VA Rating	105	Electrical Service Overseas	106
System-Specific Power Requirements	107	Power Supplies in IBM	
Personal Computers	109		
POWER-LINE CONSIDERATIONS	109		
On/Off Voltage Transients	110	Use of a Master Power Switch	
110 Power-Line Irregularities	111	Ill Effects of Power-Line Irregularities	112
POWER-CONDITIONING DEVICES	115		
The Surge Protector	115	The Backup Power Supply	117
Backup Supply Units and Power Surges	119	Pre-Power-On System	
Checkout	119	Rear-Panel AC Outlet	119
DIAGNOSTICS PROCEDURES FOR POWER-RELATED PROBLEMS	120		
Start-Up Problems	121	Problem-Isolation Techniques	124
Operation Problems	126	Power Supply Removal and Replacement	
Procedure	127	Power Supply Servicing Notes	127
6 PC System Configuration	131		
SYSTEM BOARD DESCRIPTION	131		
PC, XT, AT System Disassembly	132	PS/2 System Disassembly	
132 EISA System Disassembly	142	System Board Component	
Description	142	Memory Modules	154
System Board Adapter		Slots	155
Adapter Compatibility	155		
CONNECTORS AND CABLES	158		
Internal Device Connectors	158	External Device Connectors	
164 Cable Lengths	165	System Security	168
SYSTEM CONFIGURATION	169		
SCSI Bus Configuration	170		

PC AND XT SYSTEM CONFIGURATION 170
AT SYSTEM CONFIGURATION 171
 When to Configure 172 CMOS Data Save Program 177 PS/2
 SYSTEM CONFIGURATION 178 PS/2 Main Menu 179
EISA SYSTEM CONFIGURATION 191
 Configuration Utilities 192 The Configuration File 192 Begin
 EISA Configuration 194 Main Menu 197 Additional Main
 Menu Options 202 The System Configuration Menu Bar 203
SYSTEM BOARD TROUBLESHOOTING 207
 Speaker Problem 208 Math Coprocessor Errors 209 Battery
 Failure 209 Front-Panel LED Failure 210
UPDATING AN ISA SYSTEM 211
 System Board Component Replacement 211 AMI BIOS Example
 215 System Board Replacement 217
TROUBLESHOOTING ACCELERATED ISA SYSTEMS 219
 Software Problems 220 Hardware Problems 223 Summary
 224
CHIP-HANDLING PROCEDURES 225
 Chip Removal 225 Chip Installation 225 Chip Recovery Notes
 226

7 Memory 229

 Chapter Outline 230
 A BRIEF OVERVIEW OF COMPUTER MEMORY 230
 ROM (Read-Only Memory) 230 RAM (Random-Access
 Memory) 231 Categories of Random-Access Memory 233
 RAM Chip Organization 235
 MEMORY-EXPANSION DEVICES 236
 ROM Expansion 236 RAM Expansion 237 Memory Module
 Kit 237 Memory Expansion Kit 237 Memory Expansion Op-
 tion, Expanded Memory Adapter 237 Multifunction Adapter
 240 Contiguous-Memory Requirements 241
 SYSTEM BOARD MEMORY 242
 PC, XT, and AT Systems 242 PS/2 Systems 247 System Board
 Memory Comparison 249 System Board Memory Checks 249
 MEMORY-EXPANSION ADAPTERS 252
 MEMORY CONFIGURATION 252
 System Memory Configuration 253 Expanded Memory Con-
 figuration Notes 258
 MEMORY DIAGNOSTICS 259

ROM Error Codes	259	RAM Error Codes	260	RAM Error Codes on PS/2 Systems	261	PARITY-CHECK Error Message	262	Segment:Offset Memory Error	264
EXPANDED MEMORY DIAGNOSTICS 264									
EMS Conflicts	264	Faulty Chip Location Procedures	265						
MEMORY CONFIGURATION NOTES 271									
Error Code Interpretation	272	ISA Memory Board Switch Settings	273	Address-Shifting Techniques	276				
SOFTWARE-RELATED MEMORY DIAGNOSTICS 278									
TSR Problems	279	DOS MEM Command	280	Memory Recovery Techniques	283	Memory-Management Utilities	284		

8 Diskettes and Diskette Drives 285

Diskettes and Hard Disks	285	Source and Target Diskettes	286	Tracks and Cylinders, Sectors and Clusters	286	Reserved Sectors	289	Reserved Sector Summary	291	Recording Density, Capacity, and the Diskette Label	293	Formatting	295		
HARDWARE OVERVIEW: DRIVE SYSTEMS AND ADAPTERS 297															
Diskette Drives	297	Drive Adapters	300	Device Driver Requirements	301										
PROBLEM LOCALIZATION PROCEDURES 303															
DRIVE DIAGNOSTICS 303															
POST Problem	304	Start-Up Problems After POST	305	Drive-System Interface Checks	306	BASIC Drive-System Test	307								
DISKETTE DIAGNOSTICS 310															
Diskette Error Messages	310	Abort, Retry, Ignore, Fail Messages	310	Diskette Format Problems	312	Incompatible Diskettes	312	Choosing the Right Diskette	314	Copy-Related Problems	317	File Transfer Techniques	318		
DOS-RELATED DIAGNOSTICS 319															
DOS-Conflict Problem	319														
SOFTWARE DIAGNOSTICS 322															
System Locks Up	322	Write-Protection and Error Messages	322	Data Loss or Damage	325	Sector Damage	325	Programming-Related Problems	328	Virus Problems	331	File Recovery Techniques	331	Incompatible Software	334
DRIVE INSTALLATION AND SWAPPING PROCEDURES 334															

System-Board Diskette Configuration Procedures 335 Drive-
Swapping Procedures 336 Drive Removal and Replacement Pro-
cedures 338 Terminating Resistor Network 342 Drive Relo-
cation Note 344

9 Hard Disk Drives 345

Hard Disk Nomenclature 346 Partitions and Logical Drives 348
Partition and Logical Drive Summary 349 Hard Disk Data Encod-
ing Methods 350 System/Drive Interfaces 351 Drive Type and
Parameter Tables 355 Drive-System Interface Techniques 361
Dual-Drive Systems 362

HARD DISK INSTALLATION AND SETUP 363

PC, XT, and AT Systems 363 PS/2 Systems 364 EISA Systems
364 Internal "Hard Card" Disk Drives 365 Hard Disk Drive
Power Considerations 366 Drive Relocation Notes 366

ROUTINE MAINTENANCE TECHNIQUES 367

Hard Disk Drive Backup Procedures 367 Fragmented File Correc-
tion Techniques 371 Routine Low-Level Formatting 372

HARD DISK DIAGNOSTICS 373

Configuration Problems 373 Generally Sluggish Performance
377 Erratic Performance 377 Data Loss Problems 377 Data
Recovery Techniques 380

HARD DISK PREPARATION 383

DOS Upgrades 383 Low-Level Formatting 384 Format in
ROM BIOS 388 Format in ROM on Disk Controller 389
Utilities Diskette Format 389 DOS Installation 389 The
FDISK Utility 398 Hard Disk Capacity: Theoretical and Actual
405 Format and Partition Summary 409

DRIVE REMOVAL AND REPLACEMENT PROCEDURES 409

10 Keyboards and Mice 415

KEYBOARDS 415

Keyboard Style Description 415

KEY IDENTIFICATION 419

The Key-Cap Character 419 Keyboard Character Codes 421
Keyboard Scan Codes 423 The Key-Locator Number 427
Foreign-Language Configuration 428

KEYBOARD DIAGNOSTICS 430

Keyboard Error Codes	431	Other Keyboard-Related Problems	
432 System Security Notes	434	Status Lights	435
KEYBOARD REPAIR AND REPLACEMENT 436			
Key Reassignment	436	Keyboard Replacement	437
Mouse Installation and Diagnostics	438	Serial Mouse	438
		Bus Mouse	438
MOUSE DIAGNOSTICS 440			
Cursor Problems	440	Missing or Inoperative Cursor	440
Cursor Movement Problem	441	Mouse Button Problems	443

11 Monitors and Adapters 445

VIDEO SYSTEM TERMINOLOGY 446

Dot Pitch	446	Pixels and Pels	446	Aspect Ratio	446	Dot Pitch/Pixel Relationship	448	Monitor Performance Characteristics	449
Video Modes	450	Video Adapters	459	Digital Adapters	459	Analog Adapters	461		

MONITOR TYPES 462

Digital Monitors	463	Analog Monitors	464	Analog/Digital Monitors	465	Adapter/Monitor Compatibility	466
------------------	-----	-----------------	-----	-------------------------	-----	-------------------------------	-----

SYSTEM UNIT CONFIGURATION 467

The Primary Display Mode	467	MODE Command	470
--------------------------	-----	--------------	-----

MONITOR ADAPTER CONFIGURATION 471

Monochrome Display and Printer Adapter	471	Color/Graphics Adapter	471	Enhanced Graphics Adapter	471	Video Graphics Adapter	476	8515/A Display Adapter	477	Multiresolution Adapter	477
--	-----	------------------------	-----	---------------------------	-----	------------------------	-----	------------------------	-----	-------------------------	-----

ROUTINE MONITOR DIAGNOSTICS 478

Brightness and Contrast Controls	479	Monochrome Monitor Precautions	480	Checking the Secondary Monitor	481	Screen Blanking Utilities	481	Routine Diagnostic Test Programs	482	Extended Color Tests	485	VGA Monitor Identification	491
----------------------------------	-----	--------------------------------	-----	--------------------------------	-----	---------------------------	-----	----------------------------------	-----	----------------------	-----	----------------------------	-----

TROUBLESHOOTING DIAGNOSTICS 494

Beep Code Error Signals	494	Error Codes and Messages	496	Monitor-Adapter Memory Errors	496	Monochrome Error Codes	497	Color Error Codes	497	Visual Messages	498	Interference Problems	501	Vertical Screen Problems	501	Vertical and Horizontal Drive Problems	503	Vertical and/or Horizontal Distortion	503	EGA Character Sharpness Problem	504	Brightness and Contrast Problems	504	VGA Display Problems	505	Monitor Cable Problems	507	TV-Set Monitor Problems	508
-------------------------	-----	--------------------------	-----	-------------------------------	-----	------------------------	-----	-------------------	-----	-----------------	-----	-----------------------	-----	--------------------------	-----	--	-----	---------------------------------------	-----	---------------------------------	-----	----------------------------------	-----	----------------------	-----	------------------------	-----	-------------------------	-----

SOFTWARE-RELATED DIAGNOSTICS 508

- Incomplete or No Display 508
- Cursor Disappears off Screen 509
- Blank Area at Bottom of Screen 509
- Graphics Mode Doesn't Work 510
- HERCULES GRAPHICS CARD 510**
 - Hardware Description 511
 - Memory-Conflict Problems 513
 - Software Support 514
 - Hercules Card Diagnostics 514
 - Troubleshooting 516

12 Modems and Communications 523

HARDWARE OVERVIEW 524

Telephone System 524 Modem 524

MODEM-TO-COMPUTER INTERFACE 525

Internal Modem 525 External Modem 525 The RS-232 Standard 526

Serial Connectors and Cables 527

MODEM-TO-PHONE-LINE INTERFACE 531

MODEM CONFIGURATION 532

Serial Ports: COM1 through COM4 533

COMMUNICATIONS SOFTWARE CONFIGURATION 535

System Interface 535

COMMUNICATIONS PROTOCOL 535

Character Format 536

SOME COMMUNICATIONS NOMENCLATURE 537

Simplex 538 Duplex 538 Echo Modes 538 Baud 539

MODEM DIAGNOSTICS 539

Hardware-Related Problems 540

Diagnostics Diskette for the Internal Modem 1200 542

External Modem Diagnostics 545

Modem System Tests 546

Testing Procedure 548

Running the Tests 551

COMMUNICATION LINE PROBLEM-SOLVING TECHNIQUES 558

Secondary Phone-Line Termination 558

Call-Waiting Interruption 559

Extension Phone Interruptions 559

Carrier-Loss Problems 559

Screen-Display Problems 560

Use of a Null Modem 560

13 Printers 565

PRINTER/COMPUTER INTERFACE 566

Parallel Printer 567

Serial Printer 569

Printer Cables and Connectors 569

SYSTEM CONFIGURATION REQUIREMENTS	570
Printer Configuration	570
Hardware Configuration	574
EISA and MCA System Configuration	575
PRINTER SELECTION METHODS	578
Switching Devices	578
Cable Swapping	579
Software Switching	579
PRINTER DIAGNOSTICS	582
Diagnostics Tests	582
Printer Self-Test	583
Impact Printer Self-Test	583
Printer Wrap Test	584
PRINT-MODE CONFIGURATION	585
Default Print Mode	585
Custom Print Mode	585
Impact Printer Diagnostics	587
Inoperative Printer	587
Print-Interruption Problem	590
Print-Mode Problem	591
Erratic Printing Problems	592
LASER PRINTERS	593
Laser Printer Terminology	593
Printer Resolution in Dots	593
Laser Printer Fonts	594
Font Characteristics	594
Printer Configuration	599
LASER PRINTER DIAGNOSTICS	601
PCL: Printer Command Language	601
The Escape Sequence	602
Printer Self-Tests	603
Printer-to-Computer Interface	607
Installed Font Tests	607
Software Diagnostics	613
LASER PRINTER TROUBLESHOOTING	614
Printer Error Codes and Messages	615
Error Codes	616
Service Codes	617
Print Quality Problems	618
Paper-Related Problems	619
Toner Cartridge Problems	620

14 A Short Guide to More Help 625

The User's Manual	625
Telephone Technical Support	625
Diagnostic Software	626
IBM Technical Publications	626
CompuServe Information Service	627
Equipment Rental	632

Appendix A: DOS 5.00 635

DOS 5.00 User's Guide	635
Installation Overview	636
DOS 5.00 FEATURE SUMMARY	639
Attribute Command (ATTRIB)	639
DIRectory Command Enhancements	642
DOSKEY	644
EDIT	644
FORMAT	645
HELP SCREENS	645
LOADHIGH	646
Memory Management	646
MIRROR	648
QuickBASIC Interpreter	649

REBUILD 649 SETVER 650 UNDELETE 651 UNFOR-
MAT 653

Appendix B: Glossary and Acronyms 655

Appendix C: Error Messages And Error Codes 669

COMPLETE LIST OF ERROR CODES 671

Abbreviations Used in List of Error Codes 693

**Appendix D: Directory Of Companies and
Products 695**